User Information



EWF 1080

822 943 166-01 - 25.06.02-01

GB

Dear customer,

Please read this user information carefully.
In particular, pay attention to the section ”Safety” on the first pages. Keep this user information in a safe place for later reference. Pass it on to any subsequent owners of the unit.

Points which are necessary for your safety or which are important for the unit's functional capability are highlighted by a warning triangle and/or signal words (**Warning!, Caution!, Attention!**). Always remember.

1. This numbers guide you step by step in operating the unit.
2. ...

After this symbol you will find detailed information on operation and practical use of the unit.

The clover leaf indicates tips and information on the economical and environmentally-responsible use of the unit.

This user information contains information on remedying any faults which may occur, see the section ”What to do if ...”.

Contents

Instructions for use 5
Safety 5
Disposal 6
Environment Tips 6
Unit Description 7
Front View 7
Drawer for Detergent and Additives 7
Control Panel 8
Programme Knob 8
Additional Programme Buttons 9
Consumption values and programme times 10
Before the first wash 10
Prepare the Washing Cycle 11
Sort and Prepare the Washing 11
Types of washing and care symbols 11
Washing Detergents and Care Agents 12
Which washing detergent and care agent? 12
How much washing detergent and care agent? 12
Water Softener 12
Performing a Wash Cycle 13
Brief guide 13
Opening and Closing the Door 14
Add the Washing 14
Add detergent/additives. 15
Setting the Wash Programme 16
Changing Spin Speed /Selecting RINSE HOLD
(Spülstopp, Arrêt Cuvé Pleine) 16
Starting the Wash Programme 17
Wash Programme Progress 17
Changing the Wash Programme 18
End of Wash Cycle/Removing the Washing 18
Programme Tables 19
Washing 19
Separate Rinsing 20
Separate Spinning 20
Cleaning and Care 21
Control Panel 21
Washing Detergent Drawer 21
Washing Drum 22
Filling Door 22
Cleaning the drain pump 22
What to do, if… 24
Remedying faults 24
If the washing result is not satisfactory 26
Carry Out Emergency Emptying 27
Additional rinse cycles (RINSE+) (Spülen+, Rinçage+) 28
Child Safety Feature 29

Setting up and connection instructions 30
Technical Data / Dimensions 30
Safety Instructions for Installation 30
Setting Up the Unit 31
Transporting the Unit 31
Removing the Transit Bars/Bolts 31
Prepare the Installation Location 32
Setting Up on a Concrete Pedestal 33
Setting Up on a Vibrating floor 33
Compensate for Floor Unevenness 33
Electrical Connection 34
Water Connection 34
Permissible Water Pressure 34
Water Inflow 35
Water Drainage 36
Delivery Heads over 1 m 36
Index 37
Service 38

Instructions for use

⚠ Safety

The safety of ELECTROLUX electrical appliances conforms to the recognised technical regulations and the legislation covering the safety of appliances. However, as manufacturers, we still regard it as our responsibility to inform you of the following safety information.

Prior to initial start-up

- Refer to the "**Installation and Connection Instructions**" later in this user information.
- When the unit is delivered in winter months with minus temperatures: Store the washing machine for 24 hours at room temperature before putting it into operation.

Correct Use

- The washing machine is only designed for normal domestic washing. If the unit is used for purposes other than that for which it is designed, the manufacturer can accept no liability for any resulting damages.
- For safety reasons, conversions or modifications to the washing machine are not permissible.
- Use only detergents which are suitable for washing machines. Follow the washing detergent manufacturer's instructions.
- The washing must not contain any flammable solvents. Also remember this when washing precleaned washing.
- Do not use the washing machine for chemical cleaning.
- Dyes/dye removers may only be used in washing machines if the manufacturer expressly allows these products. We cannot be held liable for any resulting damage.
- Use only water from the water mains. Use rainwater or service water only if it meets the requirements outlined in DIN1986 and DIN1988.
- Frost damage is not covered by the warranty! If the washing machine is in a room which is at risk from frost, an emergency emptying operation must be carried out when there is a frost risk (see the section "Carry Out Emergency Emptying").

Child Safety

- Packaging components (e.g. films, polystyrene) can be hazardous to children. Risk of suffocation! Keep packaging away from children.
- Children often cannot recognise the hazards associated with handling electrical appliances. Therefore, ensure the necessary supervision during operation and do not allow children to play with the washing machine – there is a risk that children can get trapped inside.
- Ensure that children or small animals cannot climb into the washing machine's drum.
- When disposing of the washing machine: Pull out the mains plug, destroy the door lock, cut off the electrical supply lead and throw away the plug and the left-over cable. This means that children at play cannot shut themselves inside and in so doing be in danger.

General Safety

- Repairs to the washing machine may only be carried out by qualified specialists. Incorrect repairs may result in significant risk to the user. If repairs are necessary, consult our customer service or your specialist dealer.
- Never use the washing machine if the mains cable is damaged or the conrol panel, work surface or base panel area are so badly damaged that the interior of the unit is openly accessible.
- Switch off the washing machine before carrying out cleaning, care and maintenance work. Also pull the mains plug out of the socket or, – if it is permanently connected, – switch off the circuit breaker at the household power distribution box or completely remove the screw-in fuse.
- Never pull the cable to remove the plug from the socket. Always
  pull the plug itself.
- Multiple connectors, couplings and extension cables must not be used. **There is a risk of fire with overheating!**
- Do not spray down the washing machine with a water jet. Risk of electric shock!
- The glass in the door becomes hot in the case of wash programmes with high temperatures. Do not touch!
- Allow the washing solution to cool before carrying out an emergency emptying operation or cleaning the drain pump.
- Small animals can chew the power cables and water hoses. Risk of electric shock and danger of water damage! Keep small animals away from the washing machine.

Disposal

Dispose the packing material!

Dispose of your washing machine's packaging correctly. All the packaging materials used are harmless to the environment and can be recycled.

- Plastic parts are marked with standard international abbreviations:

  >PE< for polyethylene, e.g. sheet wrapping material

  >PS< for polystyrene, e.g. padding material (always CFC-free)

  >POM< for polyoxymethylene, e.g. plastic clips

- Cardboard packaging is manufactured from recycled paper and should be deposited in the waste paper collection for recycling.

Dispose the old appliance!

When you finally put your appliance out of operation, please bring it to your nearest recycling centre or to your dealer.

Environment Tips

- The pre-wash cycle is not required for averagely dirty washing. This saves washing powder/liquid, water and time (and does not harm the environment).
- The washing machine is especially economical when you fully utilise the stated filling quantities.
- For small amounts of washing, use only half to two thirds the recommended amount of washing powder/liquid.
- Suitable pretreatment enables stains and small amounts of dirt to be removed. You can then wash at a lower temperature.
- Use the energy-saving program to wash garments which are lightly to moderately dirty.
- There is often no need for conditioner. Try it once! If you use a dryer, your washing will become soft and velvety even without conditioner.
- In the case of medium to high water hardness, (hardness range II or higher, see ”Washing and Care Agents”), you should use water softener.
  The washing powder/liquid can then always be metered for hardness range I (= soft).

Unit Description

Front View


Drawer for washing powder and care agent
Control panel
Rating plate (behind filling door)
Filling door
Flap in front of drain pump
Screw feet (height-adjustable)

Drawer for Detergent and Additives

Main wash detergent (powder) and water softener if required
Pre-wash detergent/ in-wash stain treatment or water softener
Liquid additives (softeners, wash-care products to preserve the shape of garments, starch)

Control Panel



Programme Knob

The programme knob is used to set the wash cycle (for example, water level, drum movement, number of rinses, spin speed) most suitable for the type of washing, as well as the temperature of the water.



OFF (Aus, Arrêt)

- Switches the washing machine off - at all other positions the machine is on.
- It is also used to cancel programme settings selected by mistake. The original position is restored.

COTTONS/COLOUREDS (Koch-/Buntwäsche, Couleurs)

Main wash cycle for Cottons/Coloureds (cottons/linens) from 30 °C to 95 °C.

EASY-CARES (Pflegeleicht, Textiles Mélanges)

Main wash cycle for easy-care materials (mixed fibres) at 40 °C or 60 °C.

EASY IRON position: (Leichtbügeln, Facile à Repasser) Main wash cycle at 40° C for easy-care materials which, after washing with this programme, require only light ironing or no ironing at all.

DELICATES (Feinwäsche, Délicat)

Main wash programme for Delicates at 30 °C or 40 °C.

WOOL/SILK (Wolle/Seide, Laine/Soie) (Handwash)

Main wash cycle (cold or 30 °C) for machine-washable or hand-washable woollen items and silk, which bear the symbol (Handwash).

GENTLE RINSE (Feinspülen, Rinçage Délicat)
Separate gentle rinse, for example to rinse hand-washed items (3 rinses, liquid additive washed in from compartment ❀, spin).

DRAIN (Pumpen, Vidange)
Draining of the water after a Rinse Hold (without spinning).

Rinse Hold means: the washing is left to soak in the last rinse water, it is not spun.

SPIN (Schleudern, Essorage)
Draining of the water after Rinse Hold and Spin, or separate Spin for hand-washed Cottons/Coloureds.

ENERGY SAVING (Energiesparen, Eco)
Energy and water saving wash at approx. 60 °C for lightly to normally soiled Cottons/Coloureds (cottons/linen) with extended wash time (cannot be combined with QUICK WASH).

Additional Programme Buttons
The additional programme buttons are used to adjust the wash programme to the degree of soiling of the washing. For normally soiled washing, the additional functions are not necessary
Various functions can be combined together, depending on the programme.



PRE-WASH (Vorwäsche, Prélavage)
Warm pre-wash before automatically following main wash with intermediate spin for COTTONS/COLOUREDS (Koch-/Buntwäsche, Couleurs) and EASY-CARES (Pflegeleicht, Textiles Mélanges), without intermediate spin for DELICATES (Feinwäsche, Délicat).

STAIN (Flecken, Tâches)
For heavily soiled or stained washing. In-wash stain treatment products are washed in at the optimum time as the programme progresses. Can only be selected with wash temperatures of 40 °C and above, as stain treatments are only effective at higher temperatures.

QUICK WASH (Kurz, Court)
Shortened wash programme for lightly soiled washing.

With the WOOL/SILK(Wolle/Seide, Laine/Soie) (Handwash) setting, the additional programme buttons cannot be used. (Any buttons that are pressed have no effect.)

Consumption values and programme times

The values for selected programmes given in the following table were established under normal conditions. They are intended as a useful guide for normal household use.

Programme knob/Temperature	Load in kg	Water in litres	Energy in kWh	Time in minutes
COTTONS/COLOUREDS 95 (Koch-/Buntwäsche, Couleurs)	5	56	1,90	130
ENERGY SAVING 60 (Energiesparen, Eco)[1)]	5	49	0,94	125
COTTONS/COLOUREDS 40 (Koch-/Buntwäsche, Couleurs)	5	52	0,55	112
EASY-CARE 40 (Pflegeleicht, Textiles Mélanges)	2,5	56	0,45	76
DELICATES 30 (Feinwäsche, Délicat)	2,5	58	0,35	64
WOOL /SILK (Handwash) 30 (Wolle/Seide, Laine/Soie)	2	52	0,35	52

1) **Note:** Programme setting for testing in accordance with EN 60 456. Actual consumption will vary from the indicated values depending on water pressure, water hardness, water temperature at filling, room temperature, type and quantity of washing, detergent used, variations in mains voltage and any additional programme functions selected.

Before the first wash

1. Pull the detergent drawer out.
2. Pour about 1 litre of water through the detergent drawer into the washing machine. When the next programme starts, this shuts the water tank and the Economy valve can operate correctly.
3. Run a wash cycle with no washing in the drum (selecting COTTONS 95 (Kochwäsche, Couleurs), with a half-dose of detergent). This is to remove any residual substances remaining in the drum and water tank due to manufacturing processes.

Prepare the Washing Cycle

Sort and Prepare the Washing

- Sort the washing according to care codes and type (see ”Washing Types and Care Codes”).
- Empty pockets.
- Remove metal parts (paper clips, safety pins etc.).
- To prevent washing damage and washing snags: Close zip fasteners, button closed bed covers and pillow cases, and tie together ribbons, e.g. on aprons.
- Use clothing made of double-layer fabric (sleeping bag, anorak etc.).
- On knitted, coloured textiles and on wool and textiles with fitted decorations: Turn inside out.
- Wash small and sensitive items (baby socks, stockings, tights, bras etc.) in a washing net, a cushion with a zip fastener or in larger socks.
- Treat curtains with particular care. Remove small metal rollers or small, burred rollers or tie them in a net or in a bag. We cannot accept any liability for damage.
- Do not wash coloureds and whites together in one washing cycle. Otherwise, whites will discolour or turn grey.
- New coloureds often contain surplus dye. It is best to wash such items separately the first time.
- Mix small and large items of washing! This speeds up theeffect of washing and the washing is more favourably distributed during spinning.
- Loosen up the washing before loading it into the washing machine.
- Put the washing into the drum folded out.
- Pay attention to the care instructions ”Wash separately” and ”Wash separately several times”!

Types of washing and care symbols

Care symbols help you to choose the correct wash programme. Washing should be sorted by type and according to care symbols. The temperatures indicated on the care symbols are the maximum wash temperatures.

Cottons 95

Cotton and linen items with this care symbol are not sensitive to machine washing or high temperatures. The COTTONS/LINENS (Koch-/Buntwäsche, Couleurs) programme is suitable for this type of washing.

Coloureds 60 40

Cotton and linen items with this care symbol are not sensitive to machine washing. The COTTONS/LINENS (Koch-/Buntwäsche, Couleurs) programme is suitable for this type of washing.

Easy-Care washing 60 40

Materials such as fine cotton, cotton-blend fabrics, viscose and synthetics with these care symbols require a gentler machine wash. The EASYCARE/ EASY IRON (Pflegeleicht/Leichtbügeln, Textiles Mélanges/Facile à Repasser) programme is suitable for this type of washing.

Delicates 40

Materials such as layered fibres, microfibres, viscose, synthetics and net curtains with this care symbol require careful handling. The DELICATES (Feinwäsche, Délicat) programme is suitable for this types of washing.

Wool/Silk and especially sensitive washing 40

Fabrics such as wool, wool blends and silk with these care symbols are particularly sensitive to machine washing. The WOOL/SILK (Wolle/Seide, Laine/Soie) (Handwash) programme is suitable for these types of fabrics.

Important. Materials with the care symbol (Do not wash) must not be washed in the washing machine.

Washing Detergents and Care Agents

Which washing detergent and care agent?

Use only washing detergents and care agents which are suitable for use in washing machines. Always follow the manufacturer's instructions.

How much washing detergent and care agent?

The amount to be used depends on:

- the dirtiness of the washing
- the hardness category of the mains water supply
- the filling quantity

If the detergent manufacturer gives no details of the dosing quantities for minimum loads, add one third less for half loads and, in the case of very small loads and for EASY IRON (Leichtbügeln, Fâcile à Repasser), only half the amount of detergent recommended for a full load.

Refer to the detergent/care agent manufacturer's instructions on use and dosage.

Water Softener

For medium to high water hardness (hardness category II or higher) you should use water softener. Pay attention to the manufacturer's instructions. Always then meter detergent for hardness category I (= soft). The responsible water works can provide information on the local water hardness.

Since the water softener is added before the main washing detergent, (water pre-softening), eighty percent of the softener quantity stated on the package is sufficient.

Water Hardness Details

Hardness Category	Water Hardness °dH (degrees German hardness)	Water Hardness in mmol/l (millimol per litre)
I – soft	0 - 7	up to 1.3
II – medium hard	7 - 14	1.3 - 2.5
III – hard	14 - 21	2.5 - 3.8
IV – very hard	over 21	over 3.8

Performing a Wash Cycle

Brief guide

A wash cycle consists of the following steps:

1. Open the door and load the washing.
2. Close the door.
3. Add detergent/additives.
4. Set the appropriate wash programme:

– Set the programme and temperature using the programme knob
– Set additional programme functions as required.

5. Change the Spin Speed / press RINSE HOLD (Spülstopp, Arrêt Cuvé Pleine) as necessary.
6. Start the wash programme by pressing the START/PAUSE (Start/Pause, Marche / Pause) button.

After the wash programme is complete:

Important! If the wash cycle was stopped with Rinse Hold, select DRAIN (Pumpen, Vidange) or SPIN (Schleudern, Essorage) before opening the door.

7. Open the door and take out the washing.
   The door can be opened after the DOOR (Tür, Porte) light goes off and the END (Ende, Fin) light has come on.
8. Switch off the washing machine: Turn the programme knob to OFF (Aus, Arrêt).

Opening and Closing the Door

To open: pull the door by the handle.
To close: push the door in firmly

When the appliance is switched on, the DOOR (Tür, Porte) and the START/PAUSE (Start/Pause, Marche/Pause) light indicate whether the door can be opened



DOOR (Tür, Porte) light	Light START/PAUSE (Start/Pause, Marche/Pause)	Can the door be opened?
flashes	flashes	yes, after about 2 minutes
lit	lit	no[1)]
is off	flashes	yes

1) Door is locked due to high water level or high temperature.

If the END (Ende, Fin) light flashes 4 times and an acoustic signal sounds 4 times, it means there was an attempt to start a wash programme without closing the door properly. If this happens, push the door in firmly and start the wash programme again.

Add the Washing

For the maximum filling quantities, refer to the ”Program Tables”. For information on the correct preparation of the washing, see ”Sort and Prepare the Washing”.

1. Sort and prepare the washing according to type.
2. Open the filling door: Pull on the handle of the filling door.
3. Fill with washing.

Attention! When closing the door, make sure no items of washing get stuck! This could damage textiles and the unit.

4. Close the filling door securely.

Add detergent/additives

Instructions on the use of detergents and additives are contained in the section “Detergents and additives”.

1. To open the detergent/additives drawer: grasp the flap under the drawer (1) and pull the drawer out (2) till it reaches the stop.



2. Add the detergent/additives.

- **Compartment for main wash powder detergent**
  (If you use a water softener and need the right-hand compartment for the pre-wash detergent/stain treatment agent, add the water softener to the left-hand compartment with the main wash detergent.)

- **Compartment for liquid additives**
  (softeners, wash-care products to preserve the shape of garments, starch)
  Important! Do not fill the compartment past the MAX mark. Concentrated additives can be diluted to the MAX mark, dissolve powder starch.
  Note: A small amount of water remaining in the liquid additives compartment is normal and does not affect rinsing results.

- **Compartment for pre-wash detergent/ in-wash stain treatments**
  (for the additional PRE-WASH (Vorwäsche, Prélavage) or STAIN (Flecken, Tâches) programme functions only)
  or for water softener



3. Push the drawer in fully.

If using liquid detergents/tablets:
Add liquid detergent or tablets using the measure provided with the product. Follow the manufacturer's instructions on the packaging.

Setting the Wash Programme

For the correct programme, temperature and additional programme functions suitable for each type of washing, see "Programme Tables".

1. Set the programme knob to the desired programme and temperature.



2. Select any additional programme functions:
The indicator light for the selected additional programme function comes on.

– To change the selection, press another button.
– To de-select, press the button again.



Changing Spin Speed /Selecting RINSE HOLD (Spülstopp, Arrêt Cuvé Pleine)

To change the Spin Speed for the final rinse or select RINSE HOLD (Spülstopp, Arrêt Cuvé Pleine):
Keep pressing the Spin Speed/RINSE HOLD (Spülstopp, Arrêt Cuvé Pleine) button until the light for the desired speed (or RINSE HOLD (Spülstopp, Arrêt Cuvé Pleine)) comes on.
If RINSE HOLD (Spülstopp, Arrêt Cuvé Pleine) is selected, the washing is left to soak in the last rinse water, without spinning.

If the Spin Speed is not changed, the final spin is set automatically according to the wash programme:

– COTTONS/LINEN (Koch-/Buntwäsche, Couleurs) 1000 rev/min.
– ENERGY SAVING (Energiesparen, Eco) 1000 rev/min.
– EASY-CARES/EASY IRON (Pflegeleicht/Leichtbügeln, Textiles Mélanges/Facile à Repasser) 1000 rev/min.
– DELICATES (Feinwäsche, Délicat) 1000 rev/min.
– WOOL/SILK (Wolle/Seide, Laine/Soie) (Handwash) 1000 rev/min.



Starting the Wash Programme

1. Check that the stopcock is open.
2. Starting the wash programme: Press the START/ PAUSE (Start/Pause, Marche/Pause) button. The wash programme starts.

If the END (Ende, Fin) light flashes 4 times and at the same time an acoustic signal sounds 4 times when the START/PAUSE (Start/Pause, Marche/Pause) button is pressed, the door is not closed properly. If this happens, push the door firmly closed and press the START/PAUSE (Start/Pause, Marche/Pause) button again.

Wash Programme Progress

Programme Progress Display

Before the programme starts, the steps to be carried out are indicated on the Programme Progress Display. During the wash programme, this indicates the current stage of the programme.

Changing the Wash Programme

Changing or cancelling the programme

1. Press the START/PAUSE (Start/Pause, Marche/Pause) button.
2. Turn the programme knob to OFF (Aus, Arrêt). The wash programme is cancelled.
3. Set another wash programme, if required. Otherwise, turn the programme knob to DRAIN (Pumpen, Vidange) or SPIN (Schleudern, Essorage) and press the START/PAUSE (Start/Pause, Marche/Pause) button.
   (The water is drained or the washing is spun.)

The wash programme can be interrupted at any time by pressing the START/PAUSE (Start/Pause, Marche/Pause) button. It is then re-started by pressing the button again. A wash programme can only be changed after the programme knob has been turned to OFF (Aus, Arrêt).

Selecting an Additional Programme Function

The additional programme functions QUICK WASH (Kurz, Court) or STAIN (Flecken, Tâches) can still be selected after the programme has started.

1. Press the START/PAUSE (Start/Pause, Marche/Pause) button.
2. Press the QUICK WASH (Kurz, Court) or STAIN (Flecken, Tâches) button.
3. Press the START/PAUSE (Start/Pause, Marche/Pause) button again. The wash programme continues.

Changing the Spin Speed

Spin speed can still be changed or RINSE HOLD (Spülstopp, Arrêt Cuvé Pleine) set, while the programme is running.

1. Press the START/PAUSE (Start/Pause, Marche/Pause) button.
2. Change the spin speed with the Spin Speed/RINSE HOLD (Spülstopp, Arrêt Cuvé Pleine) button.
3. Press the START/PAUSE (Start/Pause, Marche/Pause) button again. The wash programme continues.

End of Wash Cycle/Removing the Washing

When a wash cycle is completed, the END (Ende, Fin) light on the Programme Progress Display comes on.
If RINSE HOLD (Spülstopp, Arrêt Cuvé Pleine) was selected, the indicator lights DOOR (Tür, Porte) and END (Ende, Fin) come on.

1. After a Rinse Hold, the water must first be drained:

– Either turn the programme knob to OFF (Aus, Arrêt), then to DRAIN (Pumpen, Vidange) and press the START/PAUSE (Start/Pause, Marche/Pause) button (the water is drained without spinning),
  or
– turn the programme knob to OFF (Aus, Arrêt), then to SPIN (Schleudern, Essorage) and press the START/PAUSE (Start/Pause, Marche/Pause) button (the water is drained and the washing is given a spin; the spin speed can be altered during the spin).

When this stage of the programme is completed, the END (Ende, Fin) light comes on.

2. Opening the door.
   The door can be opened after the DOOR (Tür, Porte) light goes off and the END (Ende, Fin) light has come on.
3. Take out the washing.
4. Turn the programme knob to OFF (Aus, Arrêt).
5. Close the stopcock.
6. After the wash cycle is completed, pull out the detergent/additives drawer slightly to allow it to dry. Leave the door slightly open to air the inside of the washing machine.

Important! If the washing machine is not used for a long time: turn off the tap and disconnect the washing machine from the mains.

Programme Tables

Washing

The tables do not show all the possible settings but only those likely to be selected for everyday operation.

Type of washing, Care symbol	max. load (Dryweight)[1]	Programme knob Temperature [in °C]	Possible additional programme functions
Cottons	5 kg	COTTONS/COLOUREDS (Koch-/Buntwäsche, Couleurs) 95	PRE-WASH (Vorwäsche, Prélavage) or STAIN (Flecken, Tâches) QUICK WASH (Kurz, Court)
Cottons/Coloureds[2]	5 kg	ENERGY SAVING (Energiesparen, Eco)	PRE-WASH (Vorwäsche, Prélavage) or STAIN (Flecken, Tâches)
Coloureds	5 kg	COTTONS/COLOUREDS (Koch-/Buntwäsche, Couleurs) 30 to 60	PRE-WASH (Vorwäsche, Prélavage) or STAIN (Flecken, Tâches)[3] QUICK WASH (Kurz, Court)
Easy-cares	2.5 kg	EASY-CARES (Pflegeleicht, Textiles Mélanges) 40, 60	PRE-WASH (Vorwäsche, Prélavage) or STAIN (Flecken, Tâches) QUICK WASH (Kurz, Court)
	1 kg	EASY IRON (Leichtbügeln, Facile à Repasser)[4] 40	
Delicates	2.5 kg (or 15-20 m^2 net curtains)	DELICATES (Feinwäsche, Délicat) 30, 40	PRE-WASH (Vorwäsche, Prélavage) QUICK WASH (Kurz, Court)
Wool/Silk (Handwashing)	2 kg	WOOL/SILK (Wolle/Seide, Laine/Soie) COLD (Kalt, Froid), 30	

1) A 10 litre bucket holds around 2.5 kg of dry clothes (cotton).
2) Programme settings for testing in accordance with or in support of EN 60 456 and IEC 60 456 are described in the chapter "Consumption Values and Programme Times“.
3) A temperature of at least 40°C is needed for the STAIN (Flecken, Tâches) programme, to make stain treatment products effective.
4) Only by keeping wash loads under 1 kg, can creasing be largely avoided. About 1 kg of dry clothes is equivalent to between 5 and 7 easy-care men's shirts.

Separate Rinsing

Type of washing	Max. load (dry weight)	Programme knob
Cottons/Linens	5kg	GENTLE RINSE (Feinspülen, Rinçage Délicat)
Easy-cares/Delicates[1)]	2.5kg	

1) Reduce spin speed.

Separate Spinning

Type of washing	Max. load (dry weight)	Programme knob
Cottons/Linens	5kg	SPIN (Schleudern, Essorage)
Easy-Cares[1)]	2.5kg	
Delicates[1)]	2.5kg	
Wool/Silk(Handwash)[1)]	2kg	

1) Reduce spin speed.

Cleaning and Care

Control Panel

Attention! For cleaning panels and control parts, do not use furniture polish or any aggressive cleaning agents.
Wipe off control panels with a damp cloth. Use warm water to do this.

Washing Detergent Drawer

The washing detergent drawer should be cleaned from time to time.

1. Pull out the washing detergent drawer as far as it will go.
2. Remove the washing detergent drawer with a firm pull.
3. Remove the softener insert from the middle compartment.



4. Clean the softener insert under running water.

5. Clean the compartments from the rear with warm water.
   It is best to use a bottle brush.



6. Push on the softener insert as far as it will go so that it is secure.

7. Use a brush to clean the entire rinsing-in part of the washing machine, especially the nozzles on the top side of the rinsing-in chamber.



8. Insert the washing detergent drawer into the guide rails and push it in.

Washing Drum

The washing drum is made of high-quality stainless steel. Rust deposits on the drum can occur due to foreign bodies in the washing which can cause rust.
Attention! Do not clean the stainless steel drum with acidic antiliming agents, scouring agents containing chlorine or iron or steel wool. Our Customer Service Department has suitable agents available.
Remove any rust deposits on the drum using a stainless steel cleaning agent.

Filling Door

Check regularly whether there are deposits or foreign bodies in the rubber sleeve behind the filling door and, if so, remove them.

Cleaning the drain pump

Paper clips, nails, etc. that might have got into the washing machine with the washing, get left in the drain pump housing. Fluff from clothes can build up on such items and so block the drain pump.
Therefore clean the drain pump at least once a year.

⚠ **Warning.** Switch the washing machine off and remove the plug from the mains before cleaning the drain pump.

1. First of all carry out an emergency drain (see the section “What to do, if.../ Emergency Drain Procedure”).
2. Place a cloth on the floor in front of the drain pump cover. Residual water can run out.
3. Unscrew the drain pump cover anti-clockwise and pull out.



4. Remove any foreign bodies such as clothes fluff from the pump housing and the pump wheel.



5. Check whether the pump wheel can turn right at the back of the pump housing. (It is normal for the pump wheel to turn jerkily.) If the pump wheel cannot turn, please inform Customer Service.



6. Replace the cover. Introduce the plates on the cover into the guide slots and turn the cover in a clockwise direction until tight.



7. Seal the emergency drain hose and lay it in the holder.



8. Close the door.

What to do, if…

Remedying faults

In the case of a fault, try to remedy the fault yourself with the help of the advice given here. If you ask Customer Service to help with one of the faults listed here or to remedy a control fault, a Customer Service Technician's visit incurs costs even during the warranty period.

Problem	Possible Cause	Remedy
The washing machine does not work.	The power plug is not connected.	Connect the plug to a power outlet.
	A domestic fuse has tripped.	Replace the fuse.
	The door is not closed properly.	Close the door; there should be an audible click.
	The START/PAUSE (Start/Pause, Marche/Pause) button was not pressed for long enough.	Press and hold the START/PAUSE (Start/Pause, Marche/Pause) button until the programme starts.
The door cannot be closed.	The child safety device is engaged.	Release the child safety device (see section "Child safety device").
The END (Ende, Fin) light flashes 4 times and at the same time an acoustic signal sounds 4 times.	The door is not closed properly.	Close the door properly. Re-start the programme.
The END (Ende, Fin) light flashes once and at the same time an acoustic signal sounds once.	The stopcock is closed.	Open the stopcock. Re-start the programme.
	The filter in the threaded inlet hose fitting is blocked.	Switch off the washing machine: Close the stopcock. Remove the plug from the mains, unscrew the hose from the stopcock, take out the filter and wash it in running water.
	Stopcock is furred with limescale or faulty.	Check the stopcock and have it repaired, if necessary.
The washing machine vibrates when operating or is noisy.	The transit bolt/bars were not removed.	Remove the transit bolts/bars as described in the Installation and Connection instructions.
	The height-adjustable screw feet have not been set correctly.	Adjust the screw feet as described in the Installation and Connection instructions.
	There is very little washing in the drum (for example, only one bathrobe).	Operation is not affected by this.
	Water could not be drained completely before spinning, because the outlet hose has got a kink in it or the drain pump is blocked.	Check the positioning of the outlet hose and even out any kinks if necessary or clean the drain pump and remove any foreign matter that might be in the pump housing.
The main wash detergent solution produces too many suds.	Probably too much detergent was used.	Follow the manufacturer's instructions exactly, when measuring out detergent.

Problem	Possible Cause	Remedy
Water runs out from under the washing machine.	The threaded inlet hose fitting is not watertight.	Screw the inlet hose in firmly.
	The outlet hose is not watertight.	Check the outlet hose and replace it, if necessary.
	The drain pump cover is not closed properly.	Close the cover properly.
	Washing has been trapped in the door.	Stop the programme and free the washing from the door. Start a new programme.
	The emergency drain hose is not connected properly or is leaking.	Connect the emergency drain hose properly (see Section "Emergency Drain Procedure“). If the emergency drain hose is leaking, call Customer Service.
Conditioner is not drawn in, the ❀ compartment for additives is full of water.	The conditioner insert is not correctly set into the additive compartment or is clogged.	Clean the detergent drawer, adjust the conditioner insert firmly.
The washing is badly rumpled.	Probably too much washing was loaded.	Keep to the maximum loads (see the Programme Tables). Select the EASY IRON (Leichtbügeln, Facile à Repasser) programme for easy-care clothes.
Washing is not spun thoroughly and water remains visible in the drum. The END (Ende, Fin) light flashes twice and at the same time an acoustic signal sounds twice.	There is a kink in the outlet hose.	Straighten the hose.
	The maximum pump height (outlet height 1 m from the washing machine’s installation surface) has been exceeded.	Contact Customer Service, who will be able to provide an adaptor kit for pump lifts greater than 1 m as a special accessory.
	The drain pump is blocked.	Switch off the machine and disconnect the mains plug. Clean the drain pump.
	Using a siphon connection: the siphon is blocked.	Clean the siphon.
The door cannot be opened when the washing machine is switched on. The indicator lights START/PAUSE (Start/Pause, Marche/Pause) and DOOR (Tür, Porte) come on.	Door is locked due to high water level or high temperature.	Wait until the wash programme has ended, the DOOR (Tür, Porte) light has gone off and the END (Ende, Fin) light has come on.
		If the door has to be opened: Turn the programme knob to OFF (Aus, Arrêt); turn the programme knob to DRAIN (Pumpen, Vidange). Press the START/PAUSE (Start/Pause, Marche/Pause) button. After the water has drained, the door can be opened.

Problem	Possible Cause	Remedy
Power failure during a wash programme (all lights have gone out).	Possibly interruption of power by the power supplier. (Door remains locked for approx. 2 minutes for safety reasons.)	Programme continues, when the power failure is over.
		If the washing is to be removed during the power failure: Turn the programme knob to OFF (Aus, Arrêt). Carry out emergency drain procedure (see section "Emergency Drain Procedure"). After approx. 2 minutes, the door can be opened by pulling on the door handle.
Detergent residues are accumulating in the detergent drawer.	The stopcock is not turned on fully.	Turn the stopcock on fully.
	The filter in the threaded inlet hose fitting is blocked at the stopcock or at the washing machine.	Close the stopcock. Unscrew the inlet hose from the stopcock and from the machine. Clean the filters.
The rinse water is cloudy.	The probable cause is a detergent high in silicate content.	This has no adverse effects on rinse results; if possible, use liquid detergent.
When pressing an additional programme function button, the corresponding light does not come on.	The selected additional programme function cannot be combined with the programme set.	Select another function.

If the washing result is not satisfactory

If the washing is grey and limescale forms in the drum

- Not enough washing detergent added.
- The right washing detergent was not used.
- Special types of stain were not pretreated.
- Program or temperature incorrectly set.
- If binary wahing detergents were used, the individual components were not added in the correct ratio.

If there are still grey stains on the washing

- Washing contaminated with creams, grease or oils was washing with too little detergent.
- Washing at too low temperature.
- A frequent cause is that conditioner – particularly concentrated form, ended up on the washing. Wash out such stains as quickly as possible and carefully use the right conditioner.

If foam is still visible after the final rinse

- Modern washing detergents can still produce foam, even in the final rinse. The washing is still sufficiently rinsed.

If there are white residues on the washing

- These are the insoluble components of modern detergents. They are not the result of an insufficient rinsing effect.
  Shake or brush off the washing. Perhaps in future you should turn the washing before washing it. Check the choice of detergent and use a liquid detergent if necessary.

Carry Out Emergency Emptying

- When the washing machine no longer pumps off the washing solution, an emergency emptying operation must be carried out.
- When the washing machine is in a room where there is a frost risk, an emergency emptying operation must be carried out when there is a frost risk.
  Also: Unscrew the intake hose from the water tap and lay it on the floor. Empty the drainage hose.

⚠ **Warning!** Switch off the washing machine before carrying out an emergency emptying operation and pull out the mains plug.
Caution! The washing solution running out of the emergency emptying hose can be hot. Risk of scalding! Allow the washing solution to cool down before carrying out emergency emptying.

1. Provide a flat collecting vessel to catch the washing solution as it runs out.
2. Open the flap downwards in the right part of the base panel and pull it off.



3. Remove the emergency emptying hose from the holder.



4. Place the collecting vessel underneath.
5. Release and pull out the plug of the emergency emptying hose by turning it anticlockwise.
   The washing solution drains off. Depending on the amount of solution, it may be necessary to empty the collecting vessel several times. To do this, temporarily close the emergency emptying hose again with the plug.



When all the washing solution has drained off:

6. Firmly push the plug into the emergency emptying hose and turn it tight clockwise.
7. Put the emergency emptying hose back into the holder.
8. Insert the flap into the base panel and close.

Additional rinse cycles (RINSE+) (Spülen+, Rinçage+)

The washing machine is set for very economical water consumption. However, for people who suffer from allergies, it can be helpful to rinse with extra water.

If RINSE+ is set, two extra rinse cycles are added to the COTTONS/LINENS (Koch-/Buntwäsche, Couleurs), EASY-CARES/ EASY IRON (Pflegeleicht/Leichtbügeln, Textiles Mélanges/Facile à Repasser) and DELICATES (Feinwäsche, Délicat) programmes.
When the machine is delivered, no additional rinse cycles are set.

To set additional rinse cycles:

1. Turn programme knob to COTTONS/LINENS (Koch-/Buntwäsche, Couleurs), EASY-CARES/ EASY IRON (Pflegeleicht/Leichtbügeln, Textiles Mélanges/Facile à Repasser) or DELICATES (Feinwäsche, Délicat) (with selected temperature).
2. Press and hold the PRE-WASH (Vorwäsche, Prélavage) and QUICK WASH (Kurz, Court) buttons at the same time for at least 2 seconds. RINSE (Spülen, Rinçage) and RINSE+ (Spülen+, Rinçage+) light up on the programme progress display. The additional rinse cycles are now set. They remain stored until cancelled again.

Additional rinse cycles increase both water consumption and programme duration.

To cancel the additional rinse cycles:

1. Turn the programme knob to COTTONS/LINENS (Koch-/Buntwäsche, Couleurs), EASY-CARES/ EASY IRON (Pflegeleicht/Leichtbügeln, Textiles Mélanges/Facile à Repasser) or DELICATES (Feinwäsche, Délicat) again.
2. Press and hold the PRE-WASH (Vorwäsche, Prélavage) and QUICK WASH (Kurz, Court) buttons at the same time for at least 2 seconds. RINSE+ (Spülen+, Rinçage) lights up on the programme progress display. The additional rinse cycles are now cancelled.

Child Safety Feature

When the child safety feature is used, the filling door can no longer be closed and no more washing programs can be started.



Setting the Child Safety Feature:

Use a coin to turn the rotary knob (on the inside of the filling door) clockwise as far as it will go.

⚠ **Warning!** The rotary knob must not be pressed in following adjustment, otherwise the child safety feature is not active. The rotary knob must project as shown in the diagram.



Cancelling the Child Safety Feature:

Turn the rotary knob anticlockwise as far as it will go.

Setting up and connection instructions

Technical Data / Dimensions

Height adjustment	Approx. +10/-5 mm
Filling quantity (program-dependent)	max. 5 kg
Use	Domestic
Drum speed, spin	see rating plate
Water pressure	1-10 bar (=10–100 N/cm^2 = 0.1–1.0 MPa)

(dimensions in mm)



Safety Instructions for Installation

- Do not tilt the washing machine onto its front or onto its right side (looking from the front). Electrical components could get wet!
- Check the washing machine for transport damage. Never connect a damaged unit. Consult your supplier in the event of damage.
- Ensure that all parts of the transport safeguard have been removed and that the splash guard is fitted to the unit, see ”Removing the Transport Safeguard”. Otherwise, damage to the unit or to adjacent furniture could occur during spinning.
- Always insert the plug into a correctly installed PE socket.
- In the case of permanent installation: A permanent installation may only be made by an authorised specialist.
- Before putting the unit into operation, ensure that the rated voltage and current type shown on the unit's rating plate are the same as the mains voltage and current type at the installation location. The required electrical fuse is also shown on the rating plate.
- The mains cable may only be replaced by the Customer Service or by an authorised specialist.

Setting Up the Unit

Washing machines with curved panels are **not suitable for substructures**.

Transporting the Unit

- Do not place the washing machine on its front side or on its right side (looking from the front). Otherwise the electrical components can get wet.
- Never transport the unit without using the transport safeguard. Do not remove the transport safeguard until you reach the installation site. Transporting the unit without the transport safeguard can result in damage to the unit.
- Never lift the unit by the open filling door or by its base.
- When transporting with the sack trolley: only place the sack trolley against the side.

Removing the Transit Bars/Bolts

Important Before the appliance is used for the first time, the transit bars/bolts must be removed. Keep all the parts of the transit bars/bolts in a safe place in case they are needed for a later journey (moving house).

1. On the back of the appliance open both hose holders and take out hoses and power cable.



2. Remove both hose holders from the appliance by pulling hard.



Special key **A** and sealing caps **B** (x 2) and **C** (x 1) come with the appliance.

3. Remove screw **D** and the spring with the special key **A**.
4. Close the hole with the sealing cap **C**.
   Important! Press the sealing cap in firmly so that it engages in the back (protects the inside of the appliance against splashes).



5. Undo two screws **E** with special key **A**.
6. Undo four screws **F** with special key **A**.
7. Remove transit bar **G**.
8. Screw in the four screws **F** again.
9. Close the two big holes with sealing cap **B**.
   Important! Press the sealing cap in firmly so that it engages in the back (protects the inside of the appliance against splashes).



Prepare the Installation Location

- The installation surface must be clean, dry and free of floor wax residue and other lubricating coatings so that the unit does not slide away. Do not use any lubricants as sliding aids.
- It is not recommended to set up the washing machine on deep-pile carpets or on floor coverings with soft foam underlays, as this would mean that the stability of the unit would not be guaranteed.
- Use ordinary rubber mats as underlays in locations with small-format tiles.
- Never use wood, card or similar underlays to compensate for minor floor unevenness. Always use the adjustable screw-type feet of the machine.
- If, for reasons of space, it is not possible to avoid setting up the unit next to a gas cooker or coal stove: Insert a thermally-insulating panel between the washing machine and the cooker (85 x 57 cm). This panel must have an aluminium foil on the side against the cooker.
- The washing machine must not be set up in a room where there is a danger of frost. Frost damage!
- The intake and drainage hoses must not be bent or pinched.

Setting Up on a Concrete Pedestal

When setting up the washing machine on a concrete pedestal, it is essential for safety reasons to fit stand plates in which the washing machine is then adjusted. The stand plates are available from the Customer Service Centre.



Setting Up on a Vibrating floor

In the case of vibrating floors, especially wooden beam floors with flexible boards, securely screw a water-resistant wooden panel at least 15mm thick onto at least 2 of the floor beams. If possible, set up the unit in a corner of the room where the wooden floor is best firmly installed and is therefore least likely to be susceptible to vibrations.

Compensate for Floor Unevenness

Floor unevenness can be compensated for and the height can be corrected with the four adjustable screw feet. The height can be adjusted in a range of +10 ... -5 mm.

To adjust the feet use the special spanner supplied for removing the transport braces.

1. Slide the special key firmly onto the hexagon head of the threaded foot as far as it will go.
2. Adjust the screw feet so that the unit is horizontal and stable. The unit must not wobble over when loaded.
3. If necessary, check the setting with a spirit level.

Attention! Never compensate for minor floor unevenness with underlays made of wood, card etc. Always adjust the adjustable feet.



Electrical Connection

Refer to the rating plate for details of the mains voltage, current type and the necessary fuses. The rating plate is located at the top behind the filling door.



CE This unit conforms to the following EU directives:

- the "Low Voltage Directive" 73/23/EU with changes
- the "EMC Directive" 89/336/EWG with changes

Water Connection

The washing machine has safety features which prevent contamination of the drinking water and which conform to the legal regulations of the water authorities (e.g. for Germany: DVGW regulations). Other protection measures in the installation are therefore not necessary.

Attention!

- Units for connection to cold water must not be connected to hot water!
- Use only new sets of hoses for connection!

Permissible Water Pressure

The water pressure must be at least 1 bar (= 10 N/cm^2 = 0.1 MPa), maximum 10 bar (= 100 N/cm^2 = 1 MPa).

- In the case of more than 10 bar: Connect a pressure-reducing valve upstream.
- In the case of less than 1 bar: Unscrew the intake hose on the unit side on the inlet solenoid valve and remove the flow regulator (to do this, remove the filter with pointed pliers and remove the rubber washer behind). Replace the filter.

Water Inflow

A pressure hose 1.35m in length is supplied.
If a longer inflow hose is required, only a VDE-approved, complete set of hoses with fitted hose screw connections offered by our Customer Service is permissible.

– Sets of hoses in lengths of 2.2m, 3.5m and 5m are available for washing machines without Aqua-Control.
– Sets of hoses in lengths of 2.0m, 2.9m and 3.9m are available for washing machines with Aqua-Control.

Attention! Never cut into pieces in order to extend the hoses!

Sealing rings are supplied either in the plastic nuts of the hose screw connection or in the enclosed pack. Do not use other seals!

1. Connect the hose with the angled connection to the machine.



Attention!
– Do not lay the supply hose vertically downwards. Rather, turn it to the right or left as shown in the diagram.
– Only tighten the screw connection manually.



2. Connect the hose with the straight connection to a water tap with a screw thread of R 3/4 (inches).
Attention! Only tighten the screw connection manually.

3. By slowly opening the water tap before putting the washing machine into operation, check whether the connection is free of leaks.



Water Drainage

The drainage hose can either be connected to a siphon or hung in a wash basin or bath tub.
Only original hoses may be used for extension purposes (max. 3m on the floor and then up to 80cm high). The Customer Service stocks hoses in lengths of 2.7 and 4m.

Attention! It is absolutely essential to install the drainage hose free of pinches.

Water Drainage into a Siphon

The grommet on the end of the hose fits all commonly used siphon types.

Secure the grommet/siphon connecting point with a hose clamp.



Draining the water into a basin

Attention!

– Small basins are not suitable for draining the water into them. Water could overflow!

– It is not permitted to submerge the end of the drainage hose into the pumped-off water. Water could be sucked up into the hose!



– When hooked into a wash-basin or a bath tub the drainage hose must be protected from slipping out of place by the supplied slip-on elbow. Otherwise the repelling power of the draining water can press the hose out of the sink.

Fix the elbow to the water tap or to the wall with string.



Delivery Heads over 1m

To pump off the washing / rinsing agent, every washing machine has a pump which transports liquids via the drainage hose up to a height of 1m, calculated from the machine's floor.

For delivery heads over 1m, consult the Customer Service.

Index

A
Additives 7, 13, 15
C
Cancelling the programme 18
Care agent 7, 12
Changing the programme 18
Child safety device 24
Child safety feature 29
Coloureds 8, 11, 19
Conditioner 6
Cottons 8, 11, 19
Curtains 11
Customer Service 22, 24, 38
D
Delicates 8, 11, 19
Detergent 7, 12, 13, 15
Detergent/additives drawer 7, 15
Drain 9
Drain pump 7, 22
Draining 18
  water 9, 18
E
Easy Iron 8, 19
Easy-Cares 8, 11, 19
Economy valve 10
Emergency emptying 27
Energy saving 9, 19
F
Frost hazard 5, 27
G
Gentle rinse 9, 20
H
Handwashable
  wool 8, 19
Handwashables 8, 19, 20
I
In-wash stain treatment 7, 15
L
Linen 11
Load 10, 19
N
Net curtains 19
O
Opening the door 14, 25
P
Pre-wash 9, 16, 19
Pre-wash detergent 7, 15
Programme progress display 8, 17
Q
Quick Wash 9, 16, 18
R
Rating plate 7, 34, 38
Rinse Hold 9, 16, 18
Rinse+ 28
S
Service 38
Silk 8, 11, 19, 20
Softener 7, 15
Spinning 9, 13, 16, 18, 20
Stain 6, 9, 16, 18, 19, 26
Synthetics 11
V
Viscose 11
W
Warranty 24
Washing powder 7, 12
Water
  hardness 6, 12
  softener 6, 7, 12, 15
Wool 8, 11, 19, 20

Service

In the section ”What to do if ...” there is a list of some faults which you can remedy yourself. Look there first if a fault occurs. If you find no information there, please consult your Customer Service Centre.
Always prepare in advance for the discussion. By doing so you will simplify the diagnosis and the decision on whether customer service is necessary.
Note the PNC-number and the S-number. Both can be found on the rating plate on the inside of the door on your washing machine



PNC: .....

S-No.: .....

Answer as precisely as possible:

- What form does the fault take?
- Under what circumstances does the fault occur?

When do you incur costs even during the warranty period?

– if you could have dealt with the fault yourself with the aid of the Faults Table (see the section ”What to do if ...”) ,
– if several trips by the customer service technician are necessary because he had not received all the necessary information before his visit and must now e.g. fetch spare parts. These multiple trips can be avoided if you prepare your phone call as described above.

Servicestellen

6032 Emmen
Buholzstrasse 1

9000 St. Gallen
Vonwilstrasse 15

8048 Zürich
Badenerstrasse 587

8604 Volketswil
Hölzliwisenstrasse 12

7000 Chur
Comercialstrasse 19

4133 Pratteln
Rheinpark-Center
Netzibodenstrasse 23b

8718 Schänis
Biltnerstrasse

3063 Ittigen
Ey 5

Ersatzteilverkauf

5506 Mägenwil
Industriestrasse 10
0848/ 848 023

Kochberatung Verkauf

8048 Zürich
Badenerstrasse 587
01/ 405 81 11

Garantie

Wir gewähren auf allen Produkten, die in der Schweiz gekauft und in Betrieb sind, eine einjährige Vollgarantie, gerechnet ab Lieferdatum an den Endverbraucher. Massgebend für den Garantieanspruch ist die Faktura oder ein entsprechender Verkaufsbeleg.

Points de Service

1028 Préverenges
Le Trési 6

Points de vente de rechange

5506 Mägenwil
Industriestrasse 10
0848/ 848 023

Demonstration/Vente

8048 Zürich
Badenerstrase 587
01/ 405 81 11

Garantie

L'utilisateur final de tout produit acheté et utilisé en Suisse, bénéficie d'une garantie complète d'une année à partir de la date de livraison. La facture ou le justificatif d'achat correspondant fait foi en la matière.

Servizio dopo vendita

6916 Grancia
Zona Industrie E

Vendita pezzi di ricambio

5506 Mägenwil
Industriestrasse 10
0848/ 848 023

Consulente (cucina) Vendita

8048 Zürich
Badenerstrasse 587
01/ 405 81 11

Garanzia

Per questo cencediamo una garanzia di 12 mesi a partire della data die vendita. La garanzia è valida dietro presentazione della fattura o dello scortrino d'acquisto.